

Operation Manual for Storers 'Airwing' Range of Chilled Multidecks




Storers 'Airwing' runs from a 13 amp plug. The system is designed to look after itself so no maintenance is required. The condenser is self-cleaning and has an automatic defrost cycle. It has front locking castors and LED lighting. The unit needs to be in a ventilated space, keeping the front grill clear to allow air flow. Clean with a damp cloth and sanitizer. Close the roller shutter evenly, don't pull on one side as this could cause the shutter to jam. Ensure the 'Airwings' are always fitted to the ends of the shelves to give the best temperature control. Only place products directly onto the shelves so as not to block airflow. See below instructions for altering the set temperature.

During normal operation **press and hold** button 1, this will display the current set temperature.

To adjust the set temperature continue to hold button 1 then either

- 1) Press and release button 2 to lower the temperature incrementally
or;
- 2) Press and release button 3 to raise the temperature incrementally

Release button 1 to store the new set temperature.



Warning! Do not press the buttons in any other sequence as this may cause the unit to fail